

WB syncro drive

In this document you'll find needed components for different type of WB EL syncro drive solutions.

Syncro drive for two benches (2 x 2 motors)

- 2 x example WB815 EL
- 2 x Cascade cable 1500mm. Code 2697
- or
- 1 x Cascade cable 500mm. Code 2696
- 1 x Special controller. Code 1262

Syncro drive for three benches (3 x 2 motors)

- 3 x example WB815 EL
- 3 x Cascade cable 1500mm. Code 2697
- 1 x Special controller. Code 1262

Syncro drive for four benches (4 x 2 motors)

- 4 x example WB815 EL
- 4 x Cascade cable 1500mm. Code 2697
- 1 x Special controller. Code 1262

How to assembly:

- Don't connect power until all cables has been connected!!
- First connect all cascade cables (code 2697) between compact boxes
- Then connect special controller (code 1262) in the wanted master bench.
- Connect power in each box
- Press down button at least 3 seconds. Tables should be now synchronized at same level.
- If syncro drive isn't working there is box resetting needed. Please contact for further quidance.