

WB EL reset

Quickstart-Manual

(For synchronus control unit)

Installation and starting up:

The following step is necessary after transport or a power fail.

Press ▼ until the lower end position is reached.

The desk moves down with half speed. Moving up is not possible.

After the desk has reached the lower end position, the control box is ready for normal operation.

Normal use:

Drive down with ▼, drive up with ▲

The desk drives with normal speed and stops automatically before reaching it's end positions

User-reset:

If the desk gets misadjusted, the lower limit of travel is to be aligned.

Press ▼ and hold this key until the desk has reached the lower end position. The desk then stops automatically.

Hold ▼. After about 5 seconds the desk slowly starts moving again until it has reached absolute limit of travel. The desk stops automatically again.